


Outside 90° Corner

Min. 3" of crushed stone required between overlapping geogrids. Increase Drainage rock zone min. in corner - Wall height / 2


-Grid Orientation - Next course place grid to run in opposite direction. Make sure strength orientation of grid is correctly placed with Uni-axial grids.



placed with Uni-axial grids.

Inside 90° Corner





Extend Wall Height / 4